

# MF: CHECKING OIL LEVEL

1-Remove the screw-top

2-Introduce the rod

3-Take out the rod and check the oil level.  
(Recommended oil: SAE 80W/90 GEAR BOX OIL)

